



Memory Lab

Mini-DV/DV Instructions



Step 1:

The Sony HD Videocassette Recorder accepts Mini-DV, DV, DVCAM, and HDV tapes. All cassettes require inspection to ensure compatibility and condition.

To start digitizing, turn on the VCR by pressing the power button at the top left.



Step 2:

Insert the tape being digitized into the VCR. All tapes must be facing with the lettering facing upward and the exposed tape side towards the VCR. Small tapes like Mini-DV must be inserted in the center of the opening.

After inserting the tape, press play or rewind to ensure starting at the beginning of the tape.



Step 3:

Once the tape begins to play, the video will be displayed on the large television. If it is satisfactory, press the record button on the ClearClick HD Capture Box. When finished recording, press the record button again.

When recording, the green light will flash and when not recording, it will be solid green.

After finishing scanning, please ask at the circulation desk for help with file transfer.